

New to Range

Sound Proofing & Heat Dispersing Mats

BA 6951, BA 6952, BA 6953



Eliminate road noise, floor pan vibration and exhaust heat from your vehicle. Bearmach Soundproofing mats create the ultimate in acoustic and thermal protection for your vehicle. Easy to install under carpets, inside doors, and around speaker boxes - enjoy your ride in any environment. The butyl rubber membrane is ideal for sound deadening road and driveline noise. High performance aluminum facing reduces engine and exhaust heat. Moulds easily to interior and door panels.

Benefits

- **Covered by Bearmach's 3-year extended warranty**
- 18" x 31" x 1/16" (460 x 800 x 1.8mm) per sheet
- 9 Sheets covers 34.8 square feet
- Thick and dense with 3 layers
- Over 20% noise reduction
- Withstands up to 350 °F (176 °C)
- Over 20% temperature reduction



| Part Number | Product | Vehicle Application |
|-------------|--------------|---------------------|
| BA 6951 | 9 Sheet Pack | All Vehicles |
| BA 6952 | 5 Sheet Pack | All Vehicles |
| BA 6953 | 2 Sheet Pack | All Vehicles |
| BA 6954 | Spare Roller | All Vehicles |



Bearmach Sound Proofing & Heat Dispersing Mats

BA 6951, BA 6952, BA 6953

Fitting Instructions

(Images shown of both under-bonnet and in-cab installation for illustration purposes)

1. Carefully strip the carpeting and padding out (if applicable) as it will be needed later to use as a template, especially the tunnel.



2. Vacuum or clean all remnants of the underlay/carpeting from the vehicle floor.

3. Wash/Clean the area to be covered with a suitable solution to remove all debris and thoroughly dry.



4. If any areas of rust, bare metal, etc. are visible rub down and treat with appropriate rust inhibitor.
5. If any sharp areas protrude, make these flush to bodywork.
6. Apply a coat of paint to these areas prior to fitment and allow to dry.



7. Once dry, measure the appropriate area or use carpet as a template, mark and cut to pattern.



8. Trial fit and once satisfied, peel a section of the backing and stick to one side of the panel being covered.



9. Remove the rest of the backing if happy with placement and tack into place. Do not fully press into position, as minor adjustments may need to be made.



10. Once satisfied, hand press into position and press firmly into recesses.



11. Once this is done, use the roller to press the mat into its final position and to find the gaps and contours.



12. Go over the mat with a soft cloth to ensure strong adhesion.

13. For any grommets or bolts, you can cut around these and remove that section.

14. Follow this process for all required areas.

