




## TF527 Steering damper relocation kit.


This kit is designed to allow the fitting of Defender style steering dampers to heavy duty steering arms. Extended bump stops should be used to avoid fouling of bracket by steering arms under extreme compression.

The Chassis plate mounts to the passenger side of the vehicle using the panhard rod bracket holes as pictured below, if a steering guard is fitted, the bottom bolt needs to be replaced with the new one from the kit.



Fit thenew chassis plate as shown below. Place two of the large M12 washers over the bolts and use as spacers between the plate and chassis. Without these spacers the plate will interfere with the tie down point.

The steering damper mounts through the lower hole (as arrowed below) on RHD vehicles.



WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defects in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or marketed by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with local laws. This warranty covers structural defect and workmanship but does not cover finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to incorrect or improper fitment or application, modified product, faulty design or consequential damage of any kind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirma shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes Ltd. The information contained in this catalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications without notice. Always consult your Allmakes/Terrafirma distributor for the latest product information and specifications. The Terrafirma range of products is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.





Put the pin end of the damper though the plate in the position show and lightly tighten.

Position the bar bracket on top of the steering bar with the 'U' section facing the chassis plate. Place the two U bolts around the bar and through the bar bracket using M8 washers and nuts tighten down until lightly clamped.

Place the eye end of the damper in line with the U section on top of the bracket and place the M10x55 bolt with washer through both items, using the other M10 washer and Nyloc nut tighten securely.



Turn steering fully to the right. Position the bar bracket to allow the damper to be fully extended and rotate for the least resistance to the bushes on the damper. Once positioned securely tighten all nuts which have been left loose. If using a Terrafirma return to Centre steering damper follow the instructions supplied with it on how to set the RTC spring.

Turn steering fully through its rotation and check for clearance against steering guard (if fitted).

If fitting to LHD vehicles then the bolt position and damper position on the chassis plate changes accordingly.

WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defects in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or marketed by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with local laws. This warranty covers structural defect and workmanship but does not cover finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to incorrect or improper filment or application, modified product, faulty design or consequential damage of any kind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirma shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes Ltd. The information contained in this catalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications without notice. Always consult your Allmakes/Terrafirma distributor for the latest product information and specifications. The Terrafirma range of products is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.