

## **CV Joint Removal**

INSTRUCTIONS

- 1. Drive vehicle for 5 miles to preheat axle lubricant.
- 2. Using a suitable container remove drain plug on axle and swivel housing and allow lubricant to drain. Re-fit drain plugs.
- 3. Jack and secure vehicle and remove road wheel.
- 4. Remove brake calliper and secure to chassis ensuring excessive strain is not applied to brake lines.
- 5. Remove hub-driving member dust cap and external cir-clip and shims from CV shaft.
- 6. Loosen bolts and remove hub-driving member.
- 7. Drift locking tab clear of wheel bearing nuts and remove wheel-bearing nuts.
- 8. With care to avoid damage to hub seal, withdraw hub from stub-axle.
- 9. Loosen and remove stub axle bolts and mud shield.
- 10. Remove stub axle from swivel housing. A light knock from a soft-faced mallet may be required to break seal.
- 11. Withdraw CV joint and axle half-shaft.

## **CV** Joint Installation

- 1. Clean remaining lubricant from interior of swivel housing.
- 2. Clean all mating faces on swivel housing, stub axle, wheel-hub and driving member.
- 3. Inspect and if necessary replace the lip seal in the swivel-ball. (If replacement is required removal of the swivelball from the main axle tube is required.)
- 4. Replacing the lip seal FRC3099 is also recommended.
- 5. Lubricate mating splines between half-shaft and CV joint and using a light tap from soft-faced mallet install the shaft into the CV joint.
- 6. Insert the half-shaft and CV assembly into the axle tube taking care to avoid damage to the seal in swivel ball and locate half-shaft in differential.
- 7. Lubricate all mating surfaces in the CV joint with swivel grease and insert the CV and half-shaft assembly into the axle.
- 8. Lubricate the stub-axle bush and lip seal with swivel grease or EP90 gear oil.
- 9. Insert the stub-axle gasket and fit the stub axle to the swivel housing, the mud shield to the stub axle and tighten the 6off retaining bolts to the specified torque (60Nm or 44lbsft).
- 10. Fit wheel-hub to stub-axle and tighten hub nuts. Ensure that a new locking washer is fitted and folded over nuts.
- 11. Fit hub-driving member and gasket and tighten 5 off retaining bolts to the specified torque (65Nm or 48lbsft).
- 12. Press on hub-driving member dust cap.
- 13. Fit brake calliper to swivel housing and tighten bolts to specified torque (60Nm or 81lbsft).
- 14. Fill differential housing with specified quantity of recommended gear oil to fill plug level.
- 15. Fill swivel housing with recommended lubricant and re-fit fill plug. (Filling is most easily accomplished with the vehicle on steering lock. Care must be taken if working on vehicles on axle stands.)
- 16. Re-fit road wheels and tighten wheel nuts to specified torque.
- 17. Test drive vehicle.

WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defects in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or marketed by it comply with the laws of the country where those goods are purchased or used. It is the sole ore responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with local laws. This warranty covers structural defect and workmanship but does not cover finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to incorrect or improper fittenent or application, modified product, faulty design or consequential damage of any kind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirms ashall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes Ld. The information contained in this catalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications. The Terrafirma and is associated companies reserve the right to alter the range and any product specifications. The Terrafirma and is associated for enhancement tam distributor is as expected.

TF2005





WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defects in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or markeled by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with local laws. This warranty covers structural defect and workmanship but does not ocver finishes, labour charges for removal or refitting, freight costs, accident damage, emisuse or abuse, damage due to incorrect or purpose other than normal private usage are not covered by this warranty. Terrafirma shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or any other company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Alimakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Alimakes Lut. The information contained in this catalogue was correct at the time of going to press. Alimakes/Terrafirma and is associated companies reserve the right to aller the range and any product specifications. The Terrafirma and is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.

TF2005